




DUST COVERS

Dust covers protect against ingress of dust, dirt or oil into the strut which can damage sealing components and reduce the life of the product.

It is recommended that in environments where dirt, sand, abrasive dust or oil contaminants are present, that dust covers should be fitted to the struts.

Dust covers can be retrofit to gas struts already in use.

HOW TO ORDER WITH A GAS STRUT



DUST COVERS

PLASTIC



DUST COVERS

COVER REFERENCE	STRUT SIZE	COVER DIAMETER
DC-SD01	6 - 15	15
DC-SD02	8 - 18	18
DC-SD03	10 - 21	21
DC-SD04	14 - 27	28
TRACTION STRUTS		
DC-TR2	8 - 22	22

FEATURES

In applications where abrasive dust and dirt particles can stick to the piston and be pulled into the gas strut during the compression stroke, fitting a dust cover can significantly increase the life expectancy of the gas strut.

These abrasive particles can wear and damage the seal, resulting in gas loss and early failure of the strut. Dust seals can also be retrofit to gas struts.

